

## ACT41000EVK-101.E1 User's Guide

### Description

This document describes the characteristics and operation of the Qorvo ACT41000EVK-101.E1 evaluation kit (EVK). It provides setup and operation instructions, schematic, layout, BOM, and test data. This EVK demonstrates the ACT41000QI101.E1 power management IC. Other ACT41000QIxxx options can be evaluated on this EVK by replacing the IC and any other necessary components.

### Features

The EVK can be used as a standalone board if desired. However, to access the internal registers and to take full advantage of the IC's capability, the user must connect the EVK to a PC with Qorvo's USB-TO-I2C interface dongle and use the GUI software. The EVK provides full access to each converter's input and output voltage, as well as all the digital control signals. This gives the user the flexibility to configure the EVK to match their real-world system.



Figure 1. EVK Picture

### EVK Contents

The ACT41000EVK-101.E1 evaluation kit comes with the following items:

1. EVK assembly
2. USB-TO-I2C dongle
  - a. Dongle
  - b. Custom 4-pin connector that connects the USB-TO-I2C dongle to the EVK assembly

**Required Equipment**

ACT41000EVK-101.E1

USB-TO-I2C Dongle

Power supply → 4~40V @ 6A for full power operation

Oscilloscope → 100MHz, 4 channels

Digital Multi-meters (DMM)

Windows compatible PC with spare USB port.

## Hardware Setup




Figure 2. EVK Setup

## Quick Start

### Hardware Connections

Refer to Figure 2 for hardware connections.

1. Connect a DC power supply to J8. J8 is connector for input voltage (VIN). Please ensure the correct power supply polarity.
2. Connect an E-Load to J9. J9 is connector for output voltage (VOUT).
3. Connect Digital Multi-Meters to VIN and VOUT to monitor the input voltage and output voltages.
4. Add a digital Multi-Meter in series with VIN and VOUT if you want to observe input and output current.
5. Be careful to keep the input voltage within the specifications.
6. Optional – Connect the EVK to the PC with the USB dongle.

### GUI Setup (optional)

1. Refer to the end of this document for detailed instructions to install the ACT41000 GUI.
2. Connect the USB-TO-I2C dongle to the computer via a USB cable.
3. Connect the USB-TO-I2C dongle to the EVK J17 connector. Refer to Figure 3 to ensure the correct

polarity of the connection. As a guide, use the “Active-Semi” (or Qorvo) logo on the top of the dongle so the black wire is connected to the Dongle GND pin.




Figure 3. USB-TO-I2C Dongle Connection

## Recommended Operating Conditions

The ACT41000EVK-101.E1 is designed for a 4V-40V input voltage. The maximum operating voltage is determined by the IC's maximum input voltage rating. The minimum operating voltage is determined by the IC's output voltage setting. The ACT41000Q1101.E1 output voltage is 5V, so the EVK should be operated with  $V_{in}$  greater than 5V. The maximum output current is configured by the CMI and external components.

**Table 1. Recommended Operating Conditions**

Parameter	Description	Min	Typ	Max	Unit
VIN	Input voltage	4	-	40	V
VOOUT	Main-buck output voltage	3	-	24	V
V5V	Mini-buck output voltage		5		V
I <sub>V5V_max</sub>	Mini-buck maximum output current		300		mA
I <sub>out_max</sub>	Main-buck maximum output current		4		A

## EVK Operation

### Turn On the Evaluation Board

After the power source and E-Load are connected to the evaluation board per the required connections, the EVK can be powered for operation. Perform the following steps to turn on the board.

1. Ensure that the power supply connected to VIN (J8) is >4V and <40V.
2. Turn on power supply.
3. Apply the load.
4. Remove the shorting jumper from J12 to enable output. Replace the jumper to disable the output.

**Output Current Limit** – The ACT41000EVK-101.E1 output current limit is set to 4A. This is a function of the 20mΩ current sense resistor (R5), the 16kΩ ILIM resistor (R9), and the I<sup>2</sup>C Output Current Limit bits, which are set to 100uA by default. The ACT41000 integrates a digital-to-analog converter (ILIM DAC) for the purpose of generating the reference signal used by the Current Limit block. The ILIM DAC generates an output current at the ILIM pin. The output current limit is easily changed by modifying any of these three parameters. The easiest way to change the output current limit is with the ILIM DAC field in the GUI.

<b>SYSTEM</b>		92. 276uA 92. 667uA 93. 058uA 93. 449uA 93. 84uA 94. 231uA 94. 622uA 95. 013uA 95. 404uA 95. 795uA 96. 186uA 96. 577uA 96. 968uA 97. 359uA 97. 75uA 98. 141uA 98. 532uA 98. 923uA 99. 314uA 99. 705uA	<input type="text" value="MainBuck Normal"/> FREQ READ <input type="text" value="450kHz"/>
<b>MAINBUCK</b>			
Current State			
I2C ADDRESS			
<b>MAINBUCK</b>			
BUCK ON			
LOAD DAC VSET			
VOUT SETTING			
TILIM DAC			
<b>MiniBUCK</b>		100. 096uA	
MiniBUCK ON			
<b>LDO</b>			
LDO ON <input type="checkbox"/>			
LDO Output Voltage		3.3V	

## Output Voltage Setting

The default output voltage can be changed by I<sup>2</sup>C using the VOUT SETTING field in the GUI. Refer to the ACT41000 datasheet before changing the output voltage. Large output voltage changes from the default setting may require changes in external components to ensure optimized performance.


<b>SYSTEM</b>		5. 1125V 5. 125V 5. 1375V 5. 15V 5. 1625V 5. 175V 5. 1875V 5. 2V 5. 2125V 5. 225V 5. 2375V 5. 25V 5. 2625V 5. 275V 5. 2875V 5. 3V 5. 3125V 5. 325V 5. 3375V 5. 35V 5. 3625V	<input type="text" value="MainBuck Normal"/> FREQ READ <input type="text" value="450kHz"/>
<b>MAINBUCK</b>			
Current State			
I2C ADDRESS			
<b>MAINBUCK</b>			
BUCK ON			
LOAD DAC VSET			
VOUT SETTING			
TILIM DAC			
<b>MiniBUCK</b>			
MiniBUCK ON			
<b>LDO</b>			
LDO ON <input type="checkbox"/>			
LDO Output Voltage		3.3V	

## Additional Programmable Functionality


The ACT41000 contains many additional programmable parameters. Refer to the ACT41000 datasheet for additional functionality and default I<sup>2</sup>C register values.

## Test Results


Main Buck Startup by EN




Main Buck Startup by Hot Plug




Main Buck Shutdown by EN




Main Buck Switching Waveform







Mini-Buck Switching Waveform



Over Current Protection - Main Buck









### Figure 4. Schematic

# Layout




Figure 5. Layout Top Layer




Figure 6. Layout Layer 2 - GND




Figure 7. Layout Layer 3 -VCC




Figure 8. Layout Bottom Layer

## Bill of Materials

**Table 2. ACT41000EVK-101.E1 BOM**

Item	Ref Des	QTY	Description	Package	MFR	Part Number
1	C1	1	Cap, Ceramic, 1uF, 50V, 20%, X5R	0805	std	std
2	C2	1	Cap, Ceramic, 10uF, 10V, 20%, X5R	0805	Wurth Elektronik	885012107010
3	C3	1	Cap, Ceramic, 1uF, 10V, 20%, X5R	0603	std	std
4	C4, C5	2	Cap, Ceramic, 1uF, 50V, 20%, X5R	0603	std	std
5	C6, C7, C18, C19, C20, C21	6	Cap, Ceramic, 10uF, 50V, 10%, X5R	1206	TDK	<a href="#">CGA5L3X5R1H106K160AB</a>
6	C8	1	Cap, Aluminium Electrolytic, 100uF, 50V	8x11.5mm	Wurth Elektronik	860010674014
7	C9	1	Cap, Ceramic, 100nF, 25V, 20%, X5R	0603	std	std
8	C10	1	Cap, Ceramic, 470pF, 50V, 20%, X5R	0603	std	std
9	C11	0	NP	0603	std	std
10	C12, C13, C14, C16	4	Cap, Ceramic, 22uF, 35V, 20%, X5R	1206	TDK	<a href="#">C3216X5R1V226M160AC</a>
11	C15	0	NP	8x11.5mm	Wurth Elektronik	860010674014
12	C17	1	Cap, Ceramic, 10uF, 25V, 10%, X5R	0603	std	std
13	C22, C23, C24, C25	0	NP	1206	TDK	<a href="#">C3216X5R1V226M160AC</a>
14	J1, J2, J3, J4, J5, J12	6	Header, 2pin, 100mil		std	std
15	J6, J7, J10, J11, J13, J14, J15, J16	8	Header, 1pin, 100mil		std	std
16	J8, J9	2	Entry modular, 2pin		Wurth Elektronik	691214110002S
17	J17	1	Header, 4 pin, 100mil		std	std
18	J18	1	Header, Unshrouded, 1.27, Male, 6P		Sullins	GRPB061VWVN-RC
19	L1	1	Inductor, 47uH, 0.71A, SMD	4mmx4mm	Wurth Elektronik	74404043470A
20	L2	1	Inductor, 3.3uH, 8.25A, SMD	8.0mmx9.0mm	Wurth Elektronik	74437358033
21	R1, R8, R10	3	Res, 0Ω, 1%	0603	std	std
22	R2,	1	Res, 100kΩ, 1%	0603	std	std
23	R3	1	Res, 10kΩ, 1%	0603	std	std
24	R4	0	NP	0603	std	std
25	R7, R11, R14	0	NP	0603	std	std
26	R5	1	Resistor, 20mΩ, 1%, 1W	1206	SART	SMF12MAFR020T
27	R6	1	Res, 84.5kΩ, 1%	0603	std	std
28	R9	1	Res, 16kΩ, 1%	0603	std	std
29	TP1, TP3, TP5, TP7	4	Test Point, Red		Keystone	TESTPOINT 5000
30	TP2, TP4, TP6, TP8, TP9	5	Test Point, Black		Keystone	TESTPOINT 5001
31	U1	1	ACT41000	QFN32-5X5	Qorvo	ACT41000QI101.E1
32	--	1	Multi-Jumper, 100mil		std	std
33	--	1	PCB, ACT41000EVK	n/a	n/a	PCB-0345-00

## GUI Installation


1. Get GUI files from the Qorvo website
2. Plug the USB-TO-I2C dongle into a free USB port.
3. Follow the instructions in the “How to install driver for dongle” folder.
4. Double click on the ActiveGUI.exe to start the ACT41000 GUI.

## GUI Overview

The GUI has 2 basic function buttons allocated in top-left of the Tool Bar which are Read and Write I<sup>2</sup>C. The GUI contains 2 setting modes: Basic Mode and Advanced Mode. In Basic Mode screen it displays basic user programmable configuration options are programmed using the drop-down boxes or check boxes. Advanced Mode contains the button text for changing setting for every single bit.

### Basic Mode

The following figure shows the GUI in basic mode. This mode allows the user to easily change one or more IC settings.



### Advanced Mode

Click the “Advanced Mode” button in the left of the GUI screen to see all available user programmable options. With Advanced Mode, additional user programmable features can be selected using the button text. In the left side of the Advanced Mode Screen, click on the Tiles Selector to display the register to view or change. Then change a register one bit at a time by clicking on the desired bit. The value of the bit is display right next to the bit-name button.

Note that the far right side of the screen contains a scroll down button to scroll down to additional registers since the Tile Screen can only display up to 8 bytes at once.

ACT41000 GUI Rev 0.0

ACT41000

Basic Mode  
Advanced Mode  
REGISTERS

Address 0x00	Address 0x01	Address 0x02	Address 0x03
RFU	BUCK_CVCC_CHG	BUCK_CC_FLT	SYNC_CLK_HIGH
RFU	RFU	BUCK_OC	SYNC_CLK_LOW
RFU	SYNC_CLK_FLT	BUCK_OVP	BUCK_MODE100
Current_State[4]	FREQ_PIN_FLT	BUCK_UVP	BUCK_IN_CC
Current_State[3]	TSD_HARD	LDO_UVP	BUCK_MODE100
Current_State[2]	TSD_SOFT	V5V_OC	BUCK_PG
Current_State[1]	RFU	V5V_OVP	LDO_PG
Current_State[0]	FVIN_OV	V5V_UVP	V5V_PG


Address 0x04	Address 0x05	Address 0x06	Address 0x07
RFU	RFU	IRQ_BK_CVCC_MSK	IRQ_BK_CC_MSK
RFU	RFU	RFU	IRQ_BK_OC_MSK
RFU	RFU	IRQ_Sync_Clk_Msk	IRQ_BK_OVP_MSK
RFU	RFU	IRQ_Freq_Pin_Msk	IRQ_BK_UVP_MSK
RFU	RFU	IRQ_Tsd_Hard_Msk	IRQ_Ldo_Uvp_Msk
RFU	RFU	IRQ_Tsd_Soft_Msk	IRQ_V5V_OC_MSK
RFU	LOAD_DAC_VSET	RFU	IRQ_V5V_OVP_MSK
RFU	BUCK_ON	IRQ_FVIN_OV_MSK	IRQ_V5V_UV_MSK

active-semi™  
Innovative Power™  
ActiveSwitcher™ is a trademark of Active-Semi.




## Button Descriptions

**Read:** Clicking on this button reads the ACT41000 registers and displays them in the GUI. Note that this reads all registers. Qorvo recommends reading registers each time the ACT41000 powers-up to acquire the initial register settings. Qorvo also recommends reading registers after making changes to them. Immediately reading the registers after a write confirms the changes were properly stored.




Read Button

**Write:** Clicking on this button writes the GUI settings to the ACT41000's registers. All registers are written, regardless of whether or not they were changed.




Write Button

**Dongle Connection Status:** The GUI also contains a dongle connection status that indicates Qorvo's USB-TO-I2C dongle is connected to the USB port. The figure below shows the two possible indication status graphics.



Dongle connected



Dongle Disconnected